



00-43 REVERB	84-85 REVERB-PHASESHIFT
44-49 AMBIANT FX	86-87 REVERB-TONE
50-58 DELAY	88-89 DELAY-REVERB
59 ECHO	90 DELAY-REVERB GATE
60-65 CHORUS	91 DELAY-REV. REVERB
66-69 FLANGER	92-93 DELAY-CHORUS
70-73 PHASE SHIFT	94-95 DELAY-CHROME
74-79 TONE	96-97 DELAY-PHASE SHIFT
80-81 REVERB-CHORUS	98-99 DELAY-TRANSPOS.
82-83 REVERB-CHROME	

